



Adventure - Portable Refrigerators

LiON Cooler X40A

LiON Cooler is the family of portable refrigerators with extractable battery to fully enjoy the freedom of travelling without giving up on comfort.

Equipped with a compact and efficient compressor which ensures excellent refrigeration performance, even in extremely high outdoor temperatures. The light and robust structure integrates two rubber wheels and an extractable telescopic handle. LiON Cooler's control unit is simple and intuitive, with a digital, user-friendly interface-and integrated Bluetooth connection to monitor functioning parameters. The extractable integrated battery ensures up to 21 hours of life and can be recharged through solar panel, 12V plug or connecting it to the power mains.

Also available in AC 115/230 V version.

Technical features

Capacity (L)	40	Dimensions (HxWxD) (mm)	509x635x405
Net weight (kg)	14,9	Consumption (kWh/24h)	0,230
Voltage (V)	DC 12, DC 24	Power absorption (W)	45
Refrigerant gas	R134a	Climate class	T
Temperature range (°C)	-20 +20	Certifications	CB, CE, EMC

